LAB 6


DNS, Web, DHCP, FTP Server configuration

Objective:

• To understand the configuration of DNS, Web, DHCP, FTP server.

DNS Server Configuration:

To create a DNS configuration two PCs are connected to a switch and the switch is connected to a Router this router is connected to a remote server as shown in the figure below:




Configuration:

Connect the PCs to the Switch using Fast Ethernet then connect the Switch to a Router then connect the Router to the Server.


For Router:

- Double click on the router and go to config and then interface.
- In Fast Ethernet 0/1, Set the port status to on and set the IP Address as 192.168.10.1.
- In Fast Ethernet 0/0, Set the port status to on and set the IP Address as 192.168.20.1.
- Close the window.




For Server:

- Double click on the Server and go to desktop and then IP Configuration.
- Set the IP Address as 192.168.10.2 and The Default Gateway as 192.168.10.1.
- Then go to Services then select DNS. Turn on DNS service.
- Add a Name and Address to host the network.
 - o If you want to modify the HTTP Page, go to HTTP and Edit as desired.



For PCs:

- Double click on the PC and go to desktop and then IP Configuration.
- Set the IP Address as 192.168.20.2 and The Default Gateway as 192.168.20.1.
- Close the window.
- Repeat the same step for the next PC and Set the IP Address as 192.168.20.3 and Gateway as 192.168.20.1.




To test for proper configuration:

- Double click on any of the PC and go to desktop.
- Open Web Browser.
- Enter the URL. If the DNS is configured the Webpage will load else some error will be displayed.



DHCP Server Configuration:

To create a DHCP Server configuration two PCs are connected to a switch and the switch is connected to a server as shown in the figure below:



Configuration:

Connect the PCs to the Switch using Fast Ethernet then connect the Switch to the Server.


Server0

For Server:

- Double click on the Server and go to desktop and then IP Configuration.
- Set the IP Address as 192.168.10.1.
- Then go to Services then select
 DHCP. Turn on DHCP service.
- Set the Pool name, Default gateway, Start IP Address, Max number of users, etc and Save/ Add it.


For PCs:

- Double click on PC and go to Desktop.
- Open IP Configuration.
- Select DHCP. If the DHCP server is configured successfully a IP Address from the given range will be assigned.



Email Server Configuration:

To create an Email Server configuration two PCs are connected to a Switch Which is then connected to a Router. The Router is connected to a remote server as shown in the figure below.




Configuration:

Connect the PCs to the Switch using Fast Ethernet then connect the Switch to a Router then connect the Router to the Server.


For Router:

- Double click on the router and go to config and then interface.
- In Fast Ethernet 0/1, Set the port status to on and set the IP Address as 192.168.10.1.
- In Fast Ethernet 0/0, Set the port status to on and set the IP Address as 192.168.20.1.
- Close the window.




For Server:

- Double click on the Server and go to desktop and then IP Configuration.
- Set the IP Address as 192.168.10.2 and The Default Gateway as 192.168.10.1.
- Then go to Services then Email. Turn on SMTP and POP3.
- Add a Domain Name and set it.
- Create users and assign password for them.




For PCs:

- Double click on the PC and go to desktop and then IP Configuration.
- Set the IP Address as 192.168.20.2 and The Default Gateway as 192.168.20.1.
- Open email and then configure it with the user details created in the server and save it.
- Close the window.
- Repeat the same step for the next PC and Set the IP Address as 192.168.20.3 and Gateway as 192.168.20.1 and configure email for different user.




To test for proper configuration:

- Double click on any of the PC and go to desktop.
- Open Email and compose a mail.
- If the email server is successfully configured email can be sent and received.



FTP Server Configuration:

To create an FTP Server configuration two PCs are connected to a Switch Which is then connected to a Router. The Router is connected to a remote server as shown in the figure below.




Configuration:

Connect the PCs to the Switch using Fast Ethernet then connect the Switch to a Router then connect the Router to the Server.


For Router:

- Double click on the router and go to config and then interface.
- In Fast Ethernet 0/1, Set the port status to on and set the IP Address as 192.168.10.1.
- In Fast Ethernet 0/0, Set the port status to on and set the IP Address as 192.168.20.1.
- Close the window.




For Server:

- Double click on the Server and go to desktop and then IP Configuration.
- Set the IP Address as 192.168.10.2 and The Default Gateway as 192.168.10.1.
- Then go to Services then FTP.
 Turn on FTP.
- Create a User by Filling Username, Password and assign them with permissions and add the user.



For PCs:

- Double click on the PC and go to desktop and then IP Configuration.
- Set the IP Address as 192.168.20.2 and The Default Gateway as 192.168.20.1.
- Close the window.
- Repeat the same step for the next PC and Set the IP Address as 192.168.20.3 and Gateway as 192.168.20.1.



To test for proper configuration:

- Double click on any of the PC and go to desktop.
- Open Command Prompt. And type Error! Hyperlink reference not valid...
- Then use username and password to login.
- If the FTP Server is setup correctly no error will be encountered.

```
Command Prompt
Cisco Packet Tracer PC Command Line 1.0
C:\>ftp 192.168.10.2
Trying to connect...192.168.10.2
Connected to 192.168.10.2
220- Welcome to PT Ftp server
Username:apple
331- Username ok, need password
Password:
230- Logged in
(passive mode On)
ftp>put test.txt
Writing file test.txt to 192.168.10.2:
File transfer in progress...
[Transfer complete - 4 bytes]
4 bytes copied in 0.367 secs (10 bytes/sec)
ftp>get test.txt
Reading file test.txt from 192.168.10.2:
File transfer in progress...
[Transfer complete - 4 bytes]
4 bytes copied in 0.01 secs (400 bytes/sec)
ftp>
```